

HAPPY WATCH COMPANY
JDC-8762-AXR MOD 3

DIRECTIONS

PLACE WATCH ABOUT WRIST. CLOSE BUCLE. DO NOT CONSTRICT. TO DISPLAY DATE, HOLD BUTTON 3, TO DISPLAY TIME RELEASE BUTTON 3. TO SET TIME, HOLD TWO BUTTONS FORCEFULLY AND PRESS BUTTON UNTIL TIME IS CORRECT. SET DATE IN THE SAME FASHION. DO NOT PUT WATER OR OTHER FLUID INTO WATCH OR WATC WILL NOT WORK. DO NOT EXCEED 32.81 FEET OF DEPTH.

THANK YOU FOR PURCHASE OF HAPPY WATCH.